

BRAKES

PARKING AND SERVICE

CONTENTS

GENERAL INFORMATION	1	SLIDING CALIPER TYPE DISC BRAKES	17
TROUBLE SHOOTING	2	DISC BRAKE PAD	18
SERVICE PROCEDURES	4	CALIPER ASSEMBLY	20
BRAKE PEDAL	6	BRAKE DISC	21
MASTER CYLINDER	8	DUO-SERVO BRAKES	22
POWER BRAKE	11	PARKING BRAKES	25
CHECKING THE CHECK VALVE	12	SPECIFICATIONS	27
BRAKE TUBES	13	SERVICING STANDARD	28
TUBES	13	TIGHTENING TORQUE	29
BLEND PROPORTIONING VALVE	14		

PARKING AND SERVICE BRAKES


CONTENTS

1	GENERAL INFORMATION	17	SLIDING CALIPER TYPE DISC BRAKES
2	TROUBLE SHOOTING	18	DISC BRAKE PAD
4	SERVICE PROCEDURES	20	CALIPER ASSEMBLY
6	BRAKE PEDAL	21	BRAKE DISC
8	MASTER CYLINDER	22	DUO-SERVO BRAKES
11	POWER BRAKE	23	PARKING BRAKES
12	CHECKING THE CHECK VALVE	27	SPECIFICATIONS
13	BRAKE TUBES	28	SERVICING STANDARD
13	TUBES	29	TIGHTENING TORQUE
14	BLEND PROPORTIONING VALVE		

GENERAL INFORMATION

The sliding caliper type disc brakes and the duo-servo brakes with automatic-adjuster are used for front and rear wheels respectively on all models.


In addition, the wheel cylinder, power brake and blend proportioning valve are common to all models.




- | | |
|-------------------------------|-------------------------|
| (1) Connector | (7) Front cable |
| (2) Blend proportioning valve | (8) Return spring |
| (3) Pull rod | (9) Parking brake lever |
| (4) Pull rod support tube | (10) Balancer |
| (5) Parking brake switch | (11) Heat protector |
| (6) Cable guide roller | (12) Rear cable |

Fig. 1 Brake System (Service and Parking)

TROUBLE SHOOTING





SERVICE PROCEDURES

INSPECTION AND ADJUSTMENT

Pedal Height Adjustment (Fig. 2)

- (1) Back off the brake light switch a little.
- (2) Loosen the jam nut on the power brake operating rod and turn the yoke on operating rod by hand or pliers to adjust the pedal height to the standard value.

Description	Standard value mm (in.)
Distance between top of pedal and toe board (top of silencer), A	166 (6.5)




Fig. 2 Brake Pedal Adjustment

- (3) Holding the yoke in position, tighten the jam nut to lock the yoke to the rod.

- (4) Do not force the stop light switch to depress the pedal lever.

If above is done with the operating rod in pushed position, the vacuum valve is closed to actuate the power brake and causes brakes to drag.

- (5) Finally make certain that the pedal has the standard amount of play and does not make any noise.

CAUTION:

If the pedal has an excessively large stroke, check the master cylinder-to-power brake push rod clearance, the brake shoe-to-drum clearance and the disc pad to disc plate dragging torque.

Description	Standard value mm (in.)
Brake pedal play	10 to 15 (.4 to .6)
Minimum distance from depressed pedal to toe board	26 (1) or more

Rear Brake Shoe Clearance Adjustment (Fig. 3)

The rear brake shoe clearance is automatically adjusted by movement of brake shoe. No adjustment is required. When the brakes are disassembled or when the adjuster fails, however, the shoe clearance should be adjusted using the following procedure.

- (1) Turn the adjuster wheel in the direction opposite to the arrow until the shoes are pressed against the drum.

- (2) With the adjuster wheel free of the adjuster lever, turn the adjuster wheel in the direction of the arrow to adjust the shoe clearance to the standard value.

Description	Standard value mm (in.)
Drum to lining clearance	0.25 to 0.40 (.010 to .016)




Fig. 3 Adjusting Brake Shoe Clearance

(3) Adjust the shoe clearance by moving the vehicle in reverse direction and depressing the brake pedal several times until the pedal stroke is constant.

Parking Brake Pull Rod Adjustment (Fig. 4)

Check to see if the parking brake pull rod has the standard amount of stroke. Adjust it if necessary.

(1) Adjust the rear brake shoe clearance to the correct dimension. [Refer to Shoe Clearance Adjustment (3)]

(2) Adjust the turnbuckle to obtain a parking brake stroke equal to the standard value when the parking brake is pulled with a force of 294N (66 lbs.).

CAUTIONS:

- Make sure that the parking brake rear cable is not taut when the pull rod is released.
- Make sure that the balancer is nearly parallel with the center line of the car.
- Ensure that clearance between the balancer and crossmember is about 200 mm (8 in.).

Description	Standard value mm (in.)	Remarks
Parking brake pull rod stroke	16 to 17 notches [Approx. 110 (4.3)]	Brakes must be applied properly at pulling force of 294N (66 lbs.)




Fig. 4 Parking Brake Adjustment


CAUTION:

After the above adjustment, the parking brake pull rod must have the standard stroke. If the stroke is larger, the rear brake automatic adjusters are malfunctioning. In such a case, disassemble and check the brakes.

(3) Prepare automatic adjuster by hand. Do not allow more than 2.5 mm (.1 in.) shoe clearance during reassembly. An excessive clearance on either side will cause malfunction of the adjuster.

(4) To adjust the parking brake switch, move the switch clamp to a position where parking brake warning light is ON when the parking brake pull rod is pulled one notch.

BRAKE PEDAL



- | | |
|----------------------------------|-------------------------------------------|
| (1) Bushing | (6) Spacer |
| (2) Support member | (7) Return spring |
| (3) Stop light switch | (8) Clutch pedal |
| (4) Pedal rod | (9) Brake pedal (Manual transmission) |
| (5) Spring (dished plane washer) | (10) Brake pedal (Automatic transmission) |

Fig. 5 Brake Pedal Control

REMOVAL

(1) Disconnect the brake pedal from the operating rod, remove the clutch cable and remove the support member with both pedals as an assembly from body.

(2) Remove the nut and clutch pedal and remove the pedal rod and brake pedal from the support member.

INSPECTION

(1) Check the bushing, pedal shaft and pad for wear, deformation and damage. Correct or replace any defective part.

(2) Check the pedals for bend and distortion. Correct or replace the pedal, if defective.

INSTALLATION

During installation, observe the following items.

(1) Apply chassis grease sufficiently to the bushing bores and flanges. Apply a thin coat of chassis grease to the clutch cable hook.

Specified grease	Quantity
MOPAR Multi-Mileage Lubricant Part Number 2525035 or equivalent	As required

(2) Tighten the pedal support to the specified torque.

Parts to be tightened	Torque Nm (ft-lbs.)
Pedal support to support member	16 to 23 (12 to 17)
Pedal support to power brake (toe board)	8 to 12 (6 to 9)


(3) Hook up the clutch cable.

(4) Adjust the clutch pedal height and the pedal free play. (Refer to GROUP 6.)

Fig. 6 Exploded View of Master Cylinder

- | | | |
|--------------------------|--------------------------------|------------------------|
| (13) Stop ring | (7) Valve case | (1) Reservoir cap |
| (14) Reservoir hose | (8) Master cylinder | (2) Fluid reservoir |
| (15) Bracket | (9) Secondary piston stop | (3) Check valve cap |
| (16) Nipple | (10) Secondary piston assembly | (4) Outer pipe seat |
| (17) Master cylinder kit | (11) Primary piston assembly | (5) Check valve |
| | (12) Piston stop | (6) Check valve spring |

MASTER CYLINDER



- | | | |
|------------------------|--------------------------------|--------------------------|
| (1) Reservoir cap | (7) Valve case | (13) Stop ring |
| (2) Fluid reservoir | (8) Master cylinder | (14) Reservoir hose |
| (3) Check valve cap | (9) Secondary piston stop | (15) Bracket |
| (4) Outer pipe seat | (10) Secondary piston assembly | (16) Nipple |
| (5) Check valve | (11) Primary piston assembly | (17) Master cylinder kit |
| (6) Check valve spring | (12) Piston stop | |

Fig. 6 Exploded View of Master Cylinder

REMOVAL

(1) After disconnecting the brake tube from the master cylinder, slowly depress the pedal to drain the fluid.

(2) After removing the master cylinder from the booster assembly, clean the cylinder.

DISASSEMBLY

(1) To disassemble the master cylinder, remove the stop ring, piston stop, primary piston assembly, secondary piston and secondary return spring in that order.

(2) Loosen the valve case and remove the check valve and the check valve spring.

(3) Wash the master cylinder, pistons and cups in brake fluid. Use care not to damage the cylinder, pistons and piston cups.

CAUTION:

Do not disassemble the primary piston assembly because the distance between spring seat (A) and spring retainer (B) is factory-adjusted by means of forming screw (C). (See Fig. 7)




Fig. 7 Sectional View of Master Cylinder

INSPECTION

(1) Check the inner surface of master cylinder and the outer surface of piston. Replace the piston if damaged.

(2) Check the master cylinder-to-piston clearance. If the clearance exceeds the service limit, replace any part that is defective.

(3) Check the piston cups for damage, deformation and wear. Replace the piston cups if defective.

(4) Check the primary and secondary return springs for loss of tension and damage. Replace any part that is defective.

CAUTION:

When any related parts such as the return spring, piston cup and piston require replacement, it is necessary to replace the piston assembly.

Description	Standard value mm (in.)	Service limit mm (in.)
Master cylinder I.D.	22.220 to 22.272 (.8748 to .8768)	
Piston O.D.	22.147 to 22.180 (.8719 to .8732)	
Cylinder-to-piston clearance	0.040 to 0.125 (.0016 to .0049)	0.150 (.0059)

ASSEMBLY

When assembling the master cylinder, observe the following items.

(1) Apply brake fluid to the master cylinder bore and the piston cup outer surface prior to assembly of the master cylinder.

Specified brake fluid	Quantity
MOPAR Brake Fluid (DOT 3) Part Number 2933249 or equivalent	As required

CAUTION:

Be careful not to damage the cylinder, pistons, and piston cups when assembling.

(2) Tighten the following parts to the specified torques when assembling the master cylinder.

Parts to be tightened	Torque Nm (ft.-lbs.)
Check valve cap	24 to 34 (18 to 25)
Check valve case	39 to 49 (29 to 36)
Secondary piston stop	1.5 to 3.0 (1.1 to 2.2)
Fluid reservoir band	2.4 to 3.9 (1.8 to 2.9)

(3) After assembling the master cylinder, check to see that the return port is not blocked by the piston cup when the piston is in the returned position.

INSTALLATION

During installation, observe the following items.

(1) Before installing the master cylinder, ascertain that the standard amount of clearance exists between the back of the master cylinder piston and the power brake push rod.

Description	Standard value mm (in.)
Clearance between back of master cylinder piston and power brake push rod	0 to 0.75 (0 to .03)

(2) Tighten the master cylinder and brake tube flare nuts to the specified torques. (See Fig. 8)

(3) After installing the master cylinder, adjust the pedal and bleed the hydraulic system.

Parts to be tightened	Symbol	Torque Nm (ft-lbs.)
Master cylinder	A	8 to 12 (6 to 9)
Brake tube flare nut	B	12 to 16 (9 to 12)
Master cylinder connector bolts	C	25 to 34 (18 to 25)




Fig. 8 Location of Tightening Torque





Fig. 7 Sectional View of Master Cylinder

POWER BRAKE



- | | |
|-----------------|------------------------------------|
| (1) Fitting | (6) Power brake (booster assembly) |
| (2) Vacuum hose | (7) Yoke |
| (3) Check valve | (8) Booster spacer |
| (4) Vacuum hose | (9) Brake booster repair kit |
| (5) Push rod | |

Fig. 9 Exploded View of Power Brake

NOTE: Power brake trouble is likely to be confused with a malfunctioning check valve; therefore a check

of the check valve should be performed first.

CHECKING THE CHECK VALVE

With the power brake side vacuum hose disconnected at the check valve, crank the engine. Holding the check valve end with fingers, feel to see if a vacuum is produced and maintained. If not, the check valve is defective; replace it.

REMOVAL

- (1) Remove the master cylinder.
- (2) Disconnect the vacuum hose from power brake.
- (3) Remove the pin connecting the power brake operating rod with the pedal.
- (4) Loosen nuts attaching power brake (fastened together with the pedal support), and take out the power brake.

INSTALLATION

During installation, observe the following instructions.

- (1) After applying a sealer to the power brake mounting surfaces (toe board and power brake surfaces), tighten power brake and the master cylinder attaching screws to the specified torques.

Parts to be tightened	Torque Nm (ft-lbs.)
Power brake	8 to 12 (6 to 9)
Master cylinder	8 to 12 (6 to 9)

- (2) When installing the check valve, observe instructions on the label of the check valve. (Fig. 10)




Fig. 10 Installing the Check Valve

- (3) Before installing the fitting, apply sealant to it so that no air will leak; then tighten it to the specified torque.

Part to be tightened	Torque Nm (ft-lbs.)
Fitting	15 to 18 (11 to 13)

- (4) Install vacuum hoses securely so that each connection will not leak air. At this point be sure sufficient clearance remains between the heater hose and the vacuum hoses.

- (5) Connect the power brake operating rod to the brake pedal and adjust the brake pedal.

NOTE: For the pedal adjustment, refer to "PEDAL ADJUSTMENT"

- (6) After bleeding the brake hydraulic system, perform the test described below.

- (a) Install pressure gauge to the brake pipe connection on the master cylinder.

- (b) Install a pedal pressure gauge to the brake pedal. Crank the engine. When the vacuum reaches 68kPa (20 in. Hg), depress the pedal, and check the hydraulic pressure to see if the standard performance is obtained.

If standard performance can not be obtained, check the power brake and the master cylinder for fluid leaks.




Fig. 11 Power Brake Performance

CAUTION:

Do not attempt to disassemble power brake units.

BRAKE TUBES

TUBES

Bleeding of Brake Hydraulic Tubes

The brake hydraulic system should be bled whenever a brake tube, brake hose, master cylinder or wheel cylinder has been removed or whenever the brake pedal feels spongy when depressed. Bleeding should be carried out in the sequence of the right rear wheel, left rear wheel, right front wheel and left front wheel (that is, bleeding should be started with the wheel cylinder farthest from the master cylinder and the bleeding of the left side rear brake is not required).

(1) Check the fluid level of the master cylinder fluid reservoir. If fluid is below specified level, add fluid.

(2) Remove the bleeder screw cap on the wheel cylinder or caliper assembly. Connect one end of a vinyl pipe to the bleeder screw and place the other end in a container (glass container of approx. 0.5 l (30 cu.in.) filled to about one half of its capacity with brake fluid.

(3) After depressing the brake pedal several times slowly, turn the bleeder screw back a little while the pedal is kept in the depressed position. Tighten the bleeder screw while the fluid is flowing in the vinyl pipe.

(4) Repeat the above operation until no air bubbles are visible in the fluid coming out from the vinyl pipe.

CAUTION:

When bleeding the system, be sure to maintain sufficient fluid in the master cylinder.

(5) Install the bleeder screw cap and replenish the fluid reservoir with brake fluid up to the MAX level.

Description	Specified brake fluid
Fluid to be used	MOPAR Brake Fluid (DOT 3) Part Number 2933249 or equivalent

CAUTION:

Use the recommended brake fluid. Avoid using a mixture of the recommended fluid and other fluid. Since the boiling point of the brake fluid is largely affected by its water content, use a 1 l (60 cu.in.) or 0.5 l (30 cu.in.) brake fluid container and make sure to close the cap of the container tightly after use.

Parts to be tightened	Torque Nm (ft-lbs.)
Bleeder screw	7 to 9 (5 to 7)
Brake tube flare nut	12 to 16 (9 to 12)
Three-way connector	25 to 34 (18 to 25)

Inspection

(1) Check the brake tube and hose for damage, interference, rust, and leaks at joints.





Fig. 12 Brake Piping System

BLEND PROPORTIONING VALVE (BPV)



- (1) Bypass valve plug (B plug)
- (2) Compression spring (B spring)
- (3) Bypass valve piston (B piston)
- (4) Bypass valve seal (B seal)
- (5) Proportioning valve seal (P seal)
- (6) Proportioning valve piston (P piston)
- (7) Compression spring (P spring)
- (8) Cup seal
- (9) Proportioning valve plug (P plug)
- (10) Body

Fig. 13 Blend Proportioning Valve

The BPV serves to improve efficiency within normal braking range by distributing braking force most effectively to the front and rear wheels. It also increases braking force to the rear wheels by releasing decompressing effect if a large braking force is required, the vehicle is loaded, or in the event that a front brake should burst.

Description	Specification	
	P ₁	P ₂
Split point	2.65 MPa (384 psi)	3.29 MPa (477 psi)
Reducing ratio	0.25	1.0




Fig. 14 Pressure Control of Rear Wheel Cylinder

Operation

F_1 : P spring force

F_2 : B spring force

A_1 : Piston sectional area

A_2 : Piston sectional area

A_3 : Bypass valve seal contacting area

P_m : Master cylinder fluid pressure

P_w : Rear wheel cylinder fluid pressure

When Proportioning Valve is out of Operation

(1) When P_m is not higher than 2.65 MPa (384 psi), P piston (6) is pushed by P spring (7) in the direction indicated by the arrow due to a lower fluid pressure (See Fig. 15). Thus the fluid from the master cylinder will not be subjected to decompression as it is delivered to the rear wheel cylinder through the gap between P piston (6) and P seal (5). The fluid pressure can be expressed by the following equation:

$$F_1 + P_m (A_2 - A_1) > P_w \times A_2$$




Fig. 15 BPV out of Operation

When Proportioning Valve is in Operation

(1) When P_m reaches 2.65 MPa (384 psi), the fluid pressure equation is in the form of:

$$F_1 + P_m (A_2 - A_1) = P_w \times A_2$$

and P_w is coming under decompression. The reducing ratio is set at 0.25.

(2) When P_m is within a range 2.65 to 3.29 MPa (384 to 477 psi), the fluid pressure relation is found to be:

$$F_1 + P_m (A_2 - A_1) \leq P_w \times A_2$$

Now, when the inequality is valid, P piston (6) is driven by P_w in the direction as indicated by the arrow and this causes the fluid circuit to be closed as P piston (6) comes in close contact with P seal (5) (See Fig. 16).

When the fluid circuit closes, the equality becomes valid.




Fig. 16 BPV in Operation (1)

As P_m further increases, P piston (6) is driven back and in an instant higher master cylinder pressure is delivered to the rear wheel cylinder between P seal and P piston. This causes P piston (6) to be driven again in the direction as indicated by the arrow shown in Fig. 15 until it comes in close contact with P seal (5) and the fluid will be closed.

Rear wheel cylinder pressure should be adjusted by repeating this pumping action.

When Bypass Valve is out of Operation

When P_m is less than 5.20 MPa (754 psi), the pressure relation is found to be:

$$P_m \times A_3 < F_2 + P_w \times A_3$$

B piston (3) will not operate.

When Bypass Valve is in Operation

(1) When P_m reaches 5.20 MPa (754 psi), the fluid pressure relation is found to be:

$$P_m \times A_3 = F_2 + P_w \times A_3$$

which shows that equal forces act on B piston (3) shutting off the bypass port between the master cylinder and the wheel cylinder. (Fig. 17)




Fig. 17 BPV in Operation (2)

This is to say that the combination of P_w (decompressed pressure) acting on the A_3 surface and B spring (2) force acting in the direction as indicated by the arrow is equal to the force of P_m acting on the A_3 surface.

(2) When P_m exceeds 5.20 MPa (754 psi), the fluid pressure relation turns to be:

$$P_m \times A_3 > F_2 + P_w \times A_3$$

This means that the reducing ratio becomes 1.0 as B position (3) is opened by the force of P_m . In this state proportioning valve is out of operation.

This is to say that P valve (6) operates between the split points P_1 and P_2 shown in Fig. 14 and B piston (3) only operates within the section above the point.

Removal and Inspection

The BPV should not be disassembled, because its performance significantly depends on the setting load.

(1) Check pipe connecting portions and plugs for fluid leakage and damage. Tighten or replace any loose or defective parts.

(2) To inspect the function of the BPV, check the hydraulic pressure of the master cylinder rear side and rear wheel cylinder side, using two pressure gauges. [10 MPa (1,500 psi.)]

Replace the BPV if the measured value is not within the range of standard value shown in the following table.

Area	Standard value	MPa (psi.)
Wheel cylinder	3.21 ± 0.20	(465.3 ± 28.4)
master cylinder	4.90	711.2
	3.92 ± 0.29	(568.9 ± 42.7)
	5.88	853.4
	4.90 ± 0.29	(711.2 ± 42.7)
	6.86	995.6

Installation

During installation, observe the following item.

(1) Tighten the BPV installing bolts to the specified torque.

Parts to be tightened	Torque	Nm (ft.-lbs.)
Brake tube flare nuts	12 to 16	(9 to 12)

DISC BRAKE PAD

Removal

- (1) Remove the wheel.
- (2) Remove the spigot pin, and pull out the stopper plug. (Fig. 19)




Fig. 19 Removing the Stopper Plug

- (3) Loosen the caliper assembly mounting, and pull the caliper assembly diagonally upward and downward repeatedly to remove it. Keep it in a clean place. (Fig. 20)




Fig. 20 Removing the Caliper Assembly

- (4) Remove the pad from the caliper support.




Fig. 21 Removing the Pad

Inspection

Make the following inspections. Replace or correct defective parts.

- (1) Check the pads for wear or oil stain.

CAUTION:

The pads on the right and left wheels should be replaced at the same time. Check the rear wheel brakes for worn shoe linings and other defects.

NOTES: 1: The remaining thickness of pads can be easily checked through the inspection hole in the caliper assembly after removing the wheel.

2: The groove in the center of the pad is not a pad wear indicator. It provides for removal of lining dust. Be careful not to confuse it with the wear indicator.

Description	Standard value mm (in.)	Service limit mm (in.)
Thickness of pad	10.5 (.41)	1.0 (.04)




Fig. 22 Checking the Pad

(2) Check the anti-rattle spring, pad clips and pad clip B for damage. (Fig. 18)

(3) Check the stopper plug and pad support plate for wear and damage.

Installation

During installation, observe the following items.

(1) When the pad has been replaced, clean the exposed part of the piston. Then, gently push the piston into the original position, taking care not to push the piston diagonally. (Fig. 23)

CAUTION:

If it is hard to push the piston with the hammer handle, loosen the bleeder screw, and the piston will go in easily. After the piston has been set in this manner, be sure to bleed the system.




Fig. 23 Forcing the Piston

(2) Install the pad clip B and the inner and outer pad clips in proper directions of installation. (Fig. 24)




Fig. 24 Installing the Clips

To check brake dragging torque, while engine is started, depress the brake pedal for about 5 seconds with the vehicle stopped, and then measure the dragging torque using a spring balance. And measure it again after the disc has been turned 10 rounds or so. If the standard value is exceeded, disassemble the caliper and check the piston sliding part for dirtiness, rust and elasticity of the piston seal.

Description	Standard value Nm (in-lbs.)	Remarks N (lbs.)
Brake dragging torque (after disc has been turned 10 rounds or so.)	4 (29) or less	Tangential force at wheel mounting bolt: 57 (12.5)

CALIPER ASSEMBLY

Removal

- (1) Remove the pads.
- (2) Pull out the hose clip from the strut area, and disconnect the brake hose from the caliper assembly.

Disassembly

- (1) Remove the dust boot. Cover the outer side of the caliper with a cloth. Inject the compressed air into the brake hose fitting to push out the piston.

CAUTION:

Do not inject high pressure air suddenly, otherwise the piston may shoot out, injuring your fingers.

- (2) Remove the piston seal taking care not to damage the cylinder.

- (3) Clean all disassembled parts in the following cleaning liquid:

- Metal partsTrichloroethylene, alcohol or brake fluid
- Piston sealBrake fluid or alcohol
- Dust boot.....Alcohol

CAUTION:

Washing the piston seal or dust boot in alcohol should be completed within 30 seconds.

Inspection

- (1) Check the cylinder and piston for wear, damage or rust. Replace defective parts.

Assembly

- (1) The piston seal and dust boot, when overhauled, must be replaced with new parts.

NOTES: 1: When replacing inner parts, use kit parts.

2: The kit parts include rubber grease. Apply the rubber grease to the piston seal.

- (2) Apply rubber grease to the piston seal and brake fluid to piston sliding parts. Insert the piston by hand being careful not to twist the seal.

NOTE: Rubber grease is semitransparent red and furnished in the seals and boots kit.

- (3) Apply the recommended grease (Niglube RX-2 grease) to the dust boot attaching groove in the caliper, and insert the dust boot.

NOTE: Niglube RX-2 grease is orange and furnished in the seals and boots kit.

- (4) Install the pad.

- (5) Apply brake grease (MOPAR Multi-Purpose Grease, Part Number 2932524 or equivalent is recommended) to the stop plug and caliper sliding surface. Install the caliper, and retain with the spigot pin.




Fig. 25 Grease Applying Point

Installation

When installing the caliper assembly, observe the following instructions referring to "Disc Brake Pads".

- (1) After tightening the brake hose to the brake hose fitting to the specified torque, bleed the brake hydraulic system.

CAUTION:

Since the wheel cylinder uses a large piston, the slightest amount of air present in the hose will seriously affect the brake pedal stroke. Bleeding, therefore, should be accomplished carefully and thoroughly.

Parts to be tightened	Torque Nm (ft.-lbs.)
Brake hose	12 to 16 (9 to 12)
Bleeder screw	7 to 9 (5 to 7)

BRAKE DISC

Removal

(1) Remove bolts attaching the caliper support to the knuckle, and hold the disc brake assembly in an appropriate position. (Fig. 26)




Fig. 26 Removing the Disc Brake Assembly

(2) Remove the hub assembly from the knuckle. Using a vice, disconnect the disc from the hub.

CAUTION:

When clamping the brake disc in a vice, copper or aluminum vice jaws must be used.

Inspection

(1) Check the disc for wear, damage and roughness on its face. Correct or replace defective parts.

Description	Standard value mm (in.)	Service limit mm (in.)
Thickness of disc	20.0 (.79)	18.4 (.72)

Installation

During installation, observe the following items.

(1) Tighten the following parts to the specified torques.

Parts to be tightened	Torque Nm (ft-lbs.)
Disc to hub	46 to 51 (34 to 38)
Caliper support	69 to 88 (51 to 65)

(2) Install the front hub.

(3) Check the disc for runout. If the runout exceeds the standard value, change the relative position of the disc to the hub. If the runout cannot be corrected by this change, replace the disc. (Fig. 27)

Description	Standard value mm (in.)
Disc runout	0.15 (.006) or less





Fig. 27 Checking Disc Runout

(4) Install the caliper assembly to the adapter and tighten to the standard torque.

Part to be tightened	Torque Nm (ft-lbs.)
Caliper assembly	69 to 88 (51 to 65)

REMOVAL

- (1) After removing the wheel, remove the brake drum.
- (2) Using a standard brake return spring tool, remove the return spring.




S14526

Fig. 29 Removing Shoe Return Spring

- (3) Remove the adjusting spring and the adjusting lever.
- (4) Remove the brake shoes and adjuster assembly then remove the cable from the parking brake lever. (Fig. 30)

CAUTION:

Note that the left and right adjuster assemblies are symmetrical construction.



S14527

Fig. 30 Removing Parking Brake Cable

- (5) After disconnecting the brake pipe from the wheel cylinder, remove the wheel cylinder from the backing plate.

- (6) Remove the backing plate together with rear axle shaft.

CAUTION:

Do not remove the backing plate unless absolutely necessary.

INSPECTION

- (1) Checking the Brake Shoes

Description	Standard value mm (in.)	Service limit mm (in.)
Thickness of shoe lining	5.4 (.213)	1.0 (.04)

- (2) Checking the Wheel Cylinders

Description	Standard value mm (in.)	Service limit mm (in.)
Wheel cylinder I.D.	19.050 to 19.102 (.750 to .752)	
Piston O.D.	18.997 to 19.030 (.7479 to .7492)	
Piston-to-cylinder clearance	0.020 to 0.105 (.0008 to .0041)	0.15 (.006)

- (3) Check the adjusting lever and adjusting latch for wear and damage. Measure the adjusting cable length (Fig. 31). Replace any part that is defective.

Description	Standard value mm (in.)
Adjusting cable length	254.5 ± 0.15 (10.020 ± .006)




Fig. 31 Measuring Adjusting Cable Length

(4) Check the inner wall of the brake drum for groove wear and presence of oil. Correct or replace the drum if it is defective.

Description	Standard value mm (in.)	Repair limit mm (in.)
Brake drum I.D.	241.3 (9.5)	243.3 (9.579)

INSTALLATION

During installation, observe the following items.

(1) Install the wheel cylinder to the backing plate by tightening it to the specified torque.

Part to be tightened	Torque Nm (ft.-lbs.)
Wheel cylinder	18 to 20 (13 to 15)

(2) Apply brake grease [MOPAR Multi-Purpose Grease (Part Number 2932524) or equivalent] to the backing plate ledge surface (A), to the contacting surfaces (B) of anchor pin and shoe web, to the contacting surfaces (C) of adjustor cable and cable guide, and to the contacting surfaces (D) of parking brake lever pin and shoe web.




Fig. 32 Greasing Points

(3) After the primary shoes have been installed, install the parking brake cable. After the adjuster assembly has been set, secure the secondary shoes.

CAUTION:

After the adjuster assembly has been cleaned, apply grease to the threaded area and check to ensure that it turns smoothly.

(4) Install the primary shoe return springs, adjusting cable and secondary shoe return springs in that order.

Note that the free length of shoe return springs differ between primary and secondary side.

	Identification color	Free length mm (in.)
Primary	Green	110.5 (4.35)
Secondary	Gray	107.5 (4.23)




Fig. 33 Installing Return Spring

(5) Install the cable and spring to the auto-adjuster lever and install to the shoes.

(6) Checking Adjuster Assembly Operation

Pull the adjuster cable toward you to see if the adjuster lever goes into mesh with the next tooth of the adjuster wheel. Check to ensure that when the cable is released, the adjuster lever returns to its original position after the adjuster wheel has moved a tooth ahead.

If the adjuster assembly does not operate correctly, perform the following checks.

- * Mounted conditions of adjusting cable and cable guide.
- * Mounted conditions of adjuster lever and adjusting spring.
- * Operation of adjuster assembly.

(7) The brake shoe lining-to-drum clearance is automatically adjusted simply by depressing the brake pedal several times.

Description	Standard value mm (in.)
Brake shoe lining-to-drum clearance	0.25 to 0.40 (.010 to .016)

(8) After the brake tube has been tightened to the specified torque, bleed the brake system.

Parts to be tightened	Torque Nm (ft-lbs.)
Brake tube flare nut	12 to 16 (9 to 12)
Bleeder screw	7 to 9 (5 to 7)

(9) Move the vehicle in reverse direction and depress the brake pedal. Repeat this until a constant pedal stroke is obtained.

PARKING BRAKES

REMOVAL

Front Cable

(1) Loosen parking brake lever fully to loosen cable. Then remove the front cable (rear end).




Fig. 34 Removing Front Cable (Rear End)

(2) Remove the pull rod assembly and parking brake switch.

(3) Withdraw the roller shaft and remove the roller.

(4) Disconnect the front cable (front end) from the pull rod. Remove the front cable and pull rod from the tube.




Fig. 35 Removing Front Cable (Front End)

Rear Cable

(1) Disconnect the rear cable under the floor and remove the return spring, parking brake lever and cable clamp.

(2) Disassembly the rear brakes.

(3) Remove the cable from the rear brake parking brake.




Fig. 36 Removing Rear Cable

INSPECTION

(1) Check the pull rod for wear of latch and damage and movement of cable. Replace the part if necessary.

INSTALLATION

During installation, observe the following items.

(1) Apply an appropriate amount of chassis grease to each sliding part.

Specified grease	Quantity
MOPAR Multi-Mileage Lubricant Part Number 2525035 or equivalent	As required

(2) Using turnbuckle, adjust cable length, so the balancer is parallel with the center line of the vehicle and the brake shoes does not drag.

(3) When the cable is installed, make certain that the cable is not twisted.

(4) To install heat protector to the boot on RH rear cable, align the groove on the heat protector with that on the No. 3 crossmember bracket. (Fig. 37)




Fig. 37 Installing the Heat Protector

(5) After the parking brakes has been adjusted, adjust the parking brake switch calmp, so brake warning light will go out with the pull rod released, and the light will come on with the pull rod pulled by one notch.




Fig. 38 Parking Brake Switch Adjustment

SPECIFICATIONS

Description	Specifications
Service Brakes	
Brake type	
Front	Sliding caliper type disc brake
Rear	Duo-servo type drum brake
Method of brake shoe clearance adjustment	
Front	Automatic adjustment type
Rear	Automatic adjustment type
Brake drum I.D.	
Rear	241.3 mm (9.5 in.)
Brake shoe lining dimensions (Length x width x thickness)	
Front (Pad dimensions)	112 x 50 x 10.5 mm (4.14 x 1.97 x .41 in.)
Rear Primary	231 x 50 x 5.4 mm (9.08 x 1.97 x .21 in.)
Secondary	262 x 50 x 5.4 mm (10.31 x 1.97 x .21 in.)
Master cylinder	
Type	Tandem type
I.D.	22.22 mm (7/8 in.) fitted with power brake
Residual pressure	
Front	0 kPa (0 psi)
Rear	0 kPa (0 psi)
Wheel cylinder I.D.	
Front	30 mm (1.181 in.)
Rear	19.05 mm (3/4 in.)
Power brake	
Type	Vacuum booster type
Effective dia. of power cylinder	190.5 mm (7.5 in.)
Booster power	3.58 [at 882N (197.1 lbs.)]
Pedal stroke	140 mm (5.5 in.)
Blend proportioning valve	Provided
Parking Brakes	
Parking brake type	Stick type
Cable arrangement	V type

SERVICING STANDARD

Description	Standard dimension	Service limit	Remarks
Service Brakes			
Brake control			
Distance between pedal top face and toe board	166 mm (6.5 in.)		
Play of pedal	10 to 15 mm (.4 to .6 in.)		
Distance from brake pedal depressed to toe board	26 mm (1 in.) or more		Pedal pressure: approx. 490N (110 lbs.)
Master cylinder			
I.D.	22.220 to 22.272 mm (.8748 to .8768 in.)		
Piston diameter	22.147 to 22.180 mm (.8719 to .8732 in.)		
Clearance between master cylinder and master cylinder piston	0.040 to 0.125 mm (.0016 to .0049 in.)	0.150 mm (.0059 in.)	
Piston-to-power brake push rod clearance	0 to 0.75 mm (0 to .03 in.)		
Disc brake			
Thickness of pad	10.5 mm (.41 in.)	1.0 mm (.04 in.)	
Thickness of disc rotor	20.0 mm (.79 in.)	18.4 mm (.72 in.)	
Dragging torque	4 Nm (29 in-lbs.) or less		Tangential force in hub bolt position: 57N (12.5 lbs.) When brake pedal is depressed
Disc runout	Less than 0.15 mm (.006 in.)		
Duo-servo brake			
Thickness of lining	5.4 mm (.213 in.)	1.0 mm (.04 in.)	
Wheel cylinder I.D.	19.050 to 19.102 mm (.750 to .752 in.)		
Piston O.D.	18.997 to 19.030 mm (.7479 to .7492 in.)		
Clearance between wheel cylinder and piston	0.020 to 0.105 mm (.0008 to .0041 in.)	0.15 mm (.006 in.)	
Brake drum I.D.	241.3 mm (9.5 in.)	243.3 mm (9.579 in.)	
Clearance between drum and lining	0.25 to 0.40 mm (.010 to .016 in.)		
Parking Brakes			
Parking brake pull rod stroke	16 to 17 notches		When pull rod assembly is pulled with 294N (66 lb.) force.
Clearance between balancer and crossmember	200 mm (8.0 in.)		

TIGHTENING TORQUE

Description	Torque	Nm (ft-lbs.)
Service Brakes		
Pedal support to support member	16 to 23	(12 to 17)
Pedal support to power brake (toe board)	8 to 12	(6 to 9)
Master cylinder		
Check valve cap tightening	24 to 34	(18 to 25)
Check valve case tightening	39 to 49	(29 to 36)
Piston stop tightening	1.5 to 3.0	(1.1 to 2.2)
Reservoir tank band tightening	2.4 to 3.9	(1.8 to 2.9)
Master cylinder installation	8 to 12	(6 to 9)
Piping flare nut tightening	12 to 16	(9 to 12)
Master cylinder connector bolt tightening	25 to 34	(18 to 25)
Power brake hose fitting tightening	15 to 18	(11 to 13)
Power brake installation	8 to 12	(6 to 9)
Bleeder screw tightening	7 to 9	(5 to 7)
Brake hose tightening	12 to 16	(9 to 12)
Three-way connector installation	25 to 34	(18 to 25)
Blend proportioning valve	11.7 to 14.6	(8.6 to 10.8)
Brake tube flare nut	12 to 16	(9 to 12)
Disc Brake		
Caliper assembly (torque plate) installation	69 to 88	(51 to 65)
Disc rotor to hub connection	46 to 51	(34 to 38)
Duo-servo brake		
Wheel cylinder installation	18 to 20	(13 to 15)
Parking Brakes		
Cable lever installation	15 to 19	(11 to 14)

TIGHTENING TORQUE

Description		Torque (in. ft-lbs)
Parking Brakes		
Cable lever installation		12 to 19 (11 to 14)
Service Brakes		
Wheel cylinder installation		18 to 20 (13 to 15)
Disc rotor to hub connection		45 to 51 (34 to 38)
Caliper assembly (torque plate) installation		69 to 88 (51 to 65)
Disc Brakes		
Brake tube flare nut		12 to 15 (9 to 12)
Blend proportioning valve		11.7 to 14.8 (8.6 to 10.8)
Three-way connector installation		22 to 34 (18 to 25)
Brake hose tightening		12 to 15 (9 to 12)
Bleeder screw tightening		7 to 9 (5 to 7)
Power brake installation		8 to 12 (6 to 9)
Power brake hose fitting tightening		15 to 18 (11 to 13)
Master cylinder connector bolt tightening		22 to 24 (18 to 22)
Piping flare nut tightening		12 to 15 (9 to 12)
Master cylinder installation		8 to 12 (6 to 9)
Reservoir tank band tightening		24 to 32 (18 to 23)
Piston stop tightening		1.5 to 3.0 (1.1 to 2.2)
Check valve case tightening		39 to 49 (29 to 36)
Check valve cap tightening		24 to 34 (18 to 25)
Master cylinder		8 to 12 (6 to 9)
Pedal support to power brake (toe board)		8 to 12 (6 to 9)
Pedal support to support member		16 to 23 (12 to 17)